

5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0404-001646	D7000	DIODE-SCHOTTKY
0404-001972	D5000	DIODE-SCHOTTKY
0406-001561	ZD6006	DIODE-TVS
0406-001592	ZD6010	DIODE-TVS
0406-001781	ZD6007,ZD6008,ZD6009	DIODE-TVS
0406-001808	D6000	DIODE-TVS
0406-001809	ZD6012,ZD6013	DIODE-TVS
0406-001829	ZD1000	DIODE-TVS
0505-002088	TR7000	FET-SILICON
0505-003234	Q6000	FET-SILICON
0601-003879	LED5000	LED
1001-001977	U2001	IC
1001-002078	SW1000,SW1001,U2004	IC
1001-002101	U1000	IC
1108-000658	UME5000	MEMORY
1201-003786	U3000	IC
1201-003915	PAM1000	IC
1201-004273	U1001	IC
1201-004285	U6001	IC
1202-001120	U6000	IC
1203-008741	U6002	IC
1203-008859	U7000	IC
1203-008867	U3002,U7001	IC
1203-008989	U7002	IC
1203-008995	U5001	IC
1203-009252	U7003	IC
1203-009434	U5000	IC
1205-005711	U3005	IC
1205-006327	UCP400	IC
1205-006337	U2005	IC
1209-002645	U3004	IC
1404-001664	TH4000,TH6000	THERMISTOR
1404-001724	TH1001	THERMISTOR
2007-000148	R5006	R-CHIP
2007-000165	R5013	R-CHIP
2007-000172	R6031	R-CHIP
2007-000242	R5014	R-CHIP
2007-000932	R4019	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-007156	R5044	R-CHIP
2007-007310	R4017,R4018	R-CHIP
2007-007517	R5005	R-CHIP
2007-007528	R4008	R-CHIP
2007-007589	R5031	R-CHIP
2007-007698	R4016	R-CHIP
2007-007741	R6001	R-CHIP
2007-008052	R4034,R4036,R7011	R-CHIP
2007-008055	R5022	R-CHIP
2007-008304	R5027	R-CHIP
2007-008312	R1012,R4021,R6023	R-CHIP
2007-008419	R4037,R5008,R5017	R-CHIP
2007-008419	R5018,R5024,R5032	R-CHIP
2007-008420	R4031,R4032	R-CHIP
2007-008478	R5016	R-CHIP
2007-008516	R4003,R4006,R4012	R-CHIP
2007-008516	R5011,R7005	R-CHIP
2007-008542	R5023,R5025	R-CHIP
2007-008588	R4015,R4023,R4024	R-CHIP
2007-008588	R4030,R5001,U7006	R-CHIP
2007-008588	U7008	R-CHIP
2007-008806	R1001	R-CHIP
2007-009157	R5015	R-CHIP
2007-009158	R5021	R-CHIP
2007-009212	R6022	R-CHIP
2007-009361	R5004,R7012,R7013	R-CHIP
2007-009410	R6007,R6008	R-CHIP
2007-009969	R6029	R-CHIP
2007-010202	L5016	R-CHIP
2007-010691	R6010	R-CHIP
2007-011532	R6004	R-CHIP
2007-011648	R1003	R-CHIP
2007-011776	R4002	R-CHIP
2007-012202	R6012,R6013	R-CHIP
2007-012590	R5012	R-CHIP
2203-000233	C7019	C-CERAMIC,CHIP
2203-001153	C5066	C-CERAMIC,CHIP
2203-005682	C1007,C4005,C4006	C-CERAMIC,CHIP
2203-005719	C1083	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005726	C1012	C-CERAMIC,CHIP
2203-005729	C6021,C6025,C7147	C-CERAMIC,CHIP
2203-005731	C3004	C-CERAMIC,CHIP
2203-005732	C6020,C6046	C-CERAMIC,CHIP
2203-005734	C5055	C-CERAMIC,CHIP
2203-005736	C1006,C1008,C1016	C-CERAMIC,CHIP
2203-005736	L3014	C-CERAMIC,CHIP
2203-005792	C1011,C1052,C1058	C-CERAMIC,CHIP
2203-005792	C1059,C1094	C-CERAMIC,CHIP
2203-006048	C3027,C5101,C5115	C-CERAMIC,CHIP
2203-006048	C6001,C6002,C6004	C-CERAMIC,CHIP
2203-006121	C6023	C-CERAMIC,CHIP
2203-006194	C3005	C-CERAMIC,CHIP
2203-006379	C3008,C6018,C7149	C-CERAMIC,CHIP
2203-006400	C1060,C5041,C5072	C-CERAMIC,CHIP
2203-006400	C5074,C6003	C-CERAMIC,CHIP
2203-006423	C2022,C2024,C2025	C-CERAMIC,CHIP
2203-006556	C1103,C5089,C5093	C-CERAMIC,CHIP
2203-006668	C6000	C-CERAMIC,CHIP
2203-006674	C5057	C-CERAMIC,CHIP
2203-006824	C5056,C6032	C-CERAMIC,CHIP
2203-006839	C1025,C1042,C1044	C-CERAMIC,CHIP
2203-006839	C1070,C2061,C5042	C-CERAMIC,CHIP
2203-006841	C3019,C5043,C5084	C-CERAMIC,CHIP
2203-006841	C5097,C5123,C7004	C-CERAMIC,CHIP
2203-006841	C7014,C7032,C7034	C-CERAMIC,CHIP
2203-006844	C5116	C-CERAMIC,CHIP
2203-006846	C1015,C1069	C-CERAMIC,CHIP
2203-006872	C4034,C5012,C5013	C-CERAMIC,CHIP
2203-006872	C5085,C5111	C-CERAMIC,CHIP
2203-007210	C4024,C4026	C-CERAMIC,CHIP
2203-007240	C4004,C5025,C5026	C-CERAMIC,CHIP
2203-007240	C5027,C5028,C5035	C-CERAMIC,CHIP
2203-007240	C5036	C-CERAMIC,CHIP
2203-007271	C5029,C5125	C-CERAMIC,CHIP
2203-007279	C5075,C6006,C6010	C-CERAMIC,CHIP
2203-007279	C7017	C-CERAMIC,CHIP
2203-007317	C2019,C2020,C5010	C-CERAMIC,CHIP
2203-007317	C5011,C5024,C5040	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007391	C4019	C-CERAMIC,CHIP
2203-007456	C5068,C5080,C6040	C-CERAMIC,CHIP
2203-007456	C7011	C-CERAMIC,CHIP
2203-007503	C5058,C5059	C-CERAMIC,CHIP
2203-007781	C5044	C-CERAMIC,CHIP
2203-007796	C3000,C3007,C3009	C-CERAMIC,CHIP
2203-007796	C3020,C3025,C4003	C-CERAMIC,CHIP
2203-007796	C4025,C4030,C4036	C-CERAMIC,CHIP
2203-007796	C4039,C4041,C4042	C-CERAMIC,CHIP
2203-007796	C4043,C4059,C5000	C-CERAMIC,CHIP
2203-007796	C5001,C5002,C5003	C-CERAMIC,CHIP
2203-007796	C5004,C5005,C5006	C-CERAMIC,CHIP
2203-007796	C5008,C5009,C5014	C-CERAMIC,CHIP
2203-007796	C5015,C5016,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5020,C5021	C-CERAMIC,CHIP
2203-007796	C5022,C5038,C5039	C-CERAMIC,CHIP
2203-007796	C5061,C5062,C5064	C-CERAMIC,CHIP
2203-007796	C5065,C5067,C5076	C-CERAMIC,CHIP
2203-007796	C5077,C5078,C5086	C-CERAMIC,CHIP
2203-007796	C5090,C5095,C5105	C-CERAMIC,CHIP
2203-007796	C5107,C5109,C5110	C-CERAMIC,CHIP
2203-007796	C5112,C5117,C5118	C-CERAMIC,CHIP
2203-007796	C5124,C6019,C7001	C-CERAMIC,CHIP
2203-007796	C7005,C7007,C7008	C-CERAMIC,CHIP
2203-008097	C6011	C-CERAMIC,CHIP
2203-008654	C6033	C-CERAMIC,CHIP
2203-008749	C7042,C7043	C-CERAMIC,CHIP
2203-008860	C5098	C-CERAMIC,CHIP
2203-008876	C1043,C1045,C1062	C-CERAMIC,CHIP
2203-009551	C7023	C-CERAMIC,CHIP
2203-009970	C1054,C5032,C5033	C-CERAMIC,CHIP
2203-009970	C5034,C5063,C6005	C-CERAMIC,CHIP
2203-010085	C5049,C5050,C5099	C-CERAMIC,CHIP
2703-002309	L6001	INDUCTOR-SMD
2703-002900	L1039	INDUCTOR-SMD
2703-002903	L1004	INDUCTOR-SMD
2703-002959	L1028,L1030,L1031	INDUCTOR-SMD
2703-004030	L2015,L3002	INDUCTOR-SMD
2703-004035	C3001,L1008,L1032	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004295	L1029	INDUCTOR-SMD
2703-004317	C3003,L1000,L1001	INDUCTOR-SMD
2703-004328	L1002,L1014,L1037	INDUCTOR-SMD
2703-004703	L3007	INDUCTOR-SMD
2703-004862	L1033,L1095	INDUCTOR-SMD
2703-004947	L6000	INDUCTOR-SMD
2703-004976	L1052	INDUCTOR-SMD
2703-005109	L5014	INDUCTOR-SMD
2703-005116	L7008	INDUCTOR-SMD
2703-005118	L7009	INDUCTOR-SMD
2703-005201	L5001,L5003	INDUCTOR-SMD
2703-005225	L5000	INDUCTOR-SMD
2703-005505	L5002,L5005	INDUCTOR-SMD
2703-005718	L1005,L3010	INDUCTOR-SMD
2801-005542	OSC5000	CRYSTAL-UNIT
2904-002241	F2004	FILTER-SAW
2904-002260	F1005	FILTER-SAW
2904-002343	F2002	FILTER-SAW
2904-002344	F2001	FILTER-SAW
2904-002381	F3000	FILTER-SAW
2904-002417	F3001	FILTER-SAW
2909-001376	F1008	FILTER-DUPLEXER
2909-001382	F1000	FILTER-DUPLEXER
2910-000342	F1004	FILTER
2910-000379	F1002	FILTER
2910-000385	F1001	FILTER
2910-000391	F1003	FILTER
2910-000419	F1006	FILTER
3003-001256	MIC6001	MIC-CONDENSOR
3301-001729	L6012	CORE-FERRITE, BEAD
3301-001885	L6003,L6013,L6017	CORE-FERRITE, BEAD
3301-001895	L3021	CORE-FERRITE, BEAD
3301-002035	L6002,L6008	CORE-FERRITE, BEAD
3301-002078	L6007,L6011,L6014	CORE-FERRITE, BEAD
3301-002078	L6015	CORE-FERRITE, BEAD
3301-002122	L6004,L6006	CORE-FERRITE, BEAD
3301-002223	L3013	CORE-FERRITE, BEAD
3301-002235	C6014,L5006,L5007	CORE-FERRITE, BEAD
3301-002235	L6005,L6009	CORE-FERRITE, BEAD

5. MAIN Electrical Parts List

3301-002236	L6016,L6120	CORE-FERRITE, BEAD
3301-002237	L1027,L1042,L2023	CORE-FERRITE, BEAD
3301-002237	L3017	CORE-FERRITE, BEAD
3301-002242	L5021	CORE-FERRITE, BEAD
3301-002243	L7010,L7011,L7012	CORE-FERRITE, BEAD
3301-002244	L1023,L7000,L7001	CORE-FERRITE, BEAD
3301-002254	L5015,L7007	CORE-FERRITE, BEAD
3404-001550	TAC5000,TAC5001	SWITCH-TACT
3404-001550	TAC5002	SWITCH-TACT
3705-001708	RFS1000	CONNECTOR-COAXIAL
3708-002162	HEA7000	CONNECTOR-FPC/FFC/PIC
3710-003193	SOC7002	CONNECTOR-SOCKET
3710-003874	HDC7000	CONNECTOR-SOCKET
3711-009045	BTC5000	CONNECTOR-HEADER
3712-001666	ANT6000,ANT6001	CONNECTOR
3712-001694	ANT1001,ANT1002	CONNECTOR
3712-001694	ANT1003,ANT2001	CONNECTOR
3712-001694	ANT2002,ANT3000	CONNECTOR
3712-001694	ANT6003	CONNECTOR
3722-003954	IFC6000	JACK-PHONE
3722-004149	EAR6000	JACK-PHONE
GH63-18831A	SC6001	-
GH63-18832A	SC6002	-
GH98-45786A	SC6003	-

5. MAIN Electrical Parts List

[SM-A013F]

Parts Code	Design LOC	Description
0505-003618	Q5000	FET-SILICON
1201-004219	U1002,U1003,U1007	IC
1201-004219	U2000,U2003	IC
2007-000143	R5035	R-CHIP
2007-003001	R6005,R6006	R-CHIP
2007-007766	R2000	R-CHIP
2007-008486	R5026	R-CHIP
2007-008516	R4013,R4022,R4026	R-CHIP
2007-008531	R5039	R-CHIP
2007-009171	R5030	R-CHIP
2007-009801	R5029	R-CHIP
2203-002677	C2037	C-CERAMIC,CHIP
2203-005682	C5094,C6012,C6015	C-CERAMIC,CHIP
2203-005682	C6016,C6017,C7037	C-CERAMIC,CHIP
2203-005682	C7041	C-CERAMIC,CHIP
2203-005736	C1022,C1024,C1030	C-CERAMIC,CHIP
2203-005736	C1031,C1032,C1034	C-CERAMIC,CHIP
2203-005736	C1038,C1050,C1053	C-CERAMIC,CHIP
2203-005736	C1064,C1065,C1071	C-CERAMIC,CHIP
2203-005736	C1076,C1078,C1080	C-CERAMIC,CHIP
2203-005736	C1089,C1092,C1099	C-CERAMIC,CHIP
2203-005736	C1111,C2002,C2005	C-CERAMIC,CHIP
2203-005736	C2009,C2010,C2011	C-CERAMIC,CHIP
2203-005736	C2012,C2013,C2014	C-CERAMIC,CHIP
2203-005736	C2015,C2016,C2017	C-CERAMIC,CHIP
2203-005736	C2018,C2021,C2023	C-CERAMIC,CHIP
2203-005736	C2027,C2028,C2029	C-CERAMIC,CHIP
2203-005736	C2032,C2033,C2034	C-CERAMIC,CHIP
2203-005736	C2036,C2038,C2039	C-CERAMIC,CHIP
2203-005736	C2040,C2042,C2047	C-CERAMIC,CHIP
2203-005736	C2048,C2049,C2050	C-CERAMIC,CHIP
2203-005736	C2052,C2056,C2057	C-CERAMIC,CHIP
2203-005736	C2059,C2068,C2069	C-CERAMIC,CHIP
2203-005736	C2097,C2099,C3002	C-CERAMIC,CHIP
2203-005736	C3006,C3010,C3011	C-CERAMIC,CHIP
2203-005736	C3013,C3014,C3028	C-CERAMIC,CHIP
2203-005736	C3029,C3030,C3031	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005736	C6008,C7022,C7025	C-CERAMIC,CHIP
2203-005736	L1043,L1050,L3009	C-CERAMIC,CHIP
2203-005777	C1039,C1040,C1041	C-CERAMIC,CHIP
2203-005777	C1084	C-CERAMIC,CHIP
2203-005789	C1000,C1013,C1017	C-CERAMIC,CHIP
2203-005789	C1019,C1033,C1037	C-CERAMIC,CHIP
2203-005789	C1051,C1061,C1063	C-CERAMIC,CHIP
2203-005789	C1074,C1090,C1091	C-CERAMIC,CHIP
2203-005789	C1095,C2092,L3019	C-CERAMIC,CHIP
2203-005806	C1067,C1072,C1073	C-CERAMIC,CHIP
2203-005806	C1152,C2004,C3016	C-CERAMIC,CHIP
2203-006123	C2041,L3000	C-CERAMIC,CHIP
2203-006305	C1077	C-CERAMIC,CHIP
2203-006318	C1088,C2091	C-CERAMIC,CHIP
2203-006410	C1048,C2093	C-CERAMIC,CHIP
2203-006423	C1049,C1104,C2001	C-CERAMIC,CHIP
2203-006423	C2026,C2046,C2066	C-CERAMIC,CHIP
2203-006423	C2067,C3026,C4002	C-CERAMIC,CHIP
2203-006423	C4017,C4020,C4021	C-CERAMIC,CHIP
2203-006423	C4027,C4029,C4031	C-CERAMIC,CHIP
2203-006423	C4033,C4035,C4037	C-CERAMIC,CHIP
2203-006423	C4038,C4040,C4044	C-CERAMIC,CHIP
2203-006423	C4060,C4061,C4065	C-CERAMIC,CHIP
2203-006423	C4067,C4068,C5037	C-CERAMIC,CHIP
2203-006423	C5045,C5046,C5053	C-CERAMIC,CHIP
2203-006423	C5054,C5073,C5081	C-CERAMIC,CHIP
2203-006423	C5091,C5092,C5120	C-CERAMIC,CHIP
2203-006423	C5121,C7144,C7146	C-CERAMIC,CHIP
2203-006604	C1027	C-CERAMIC,CHIP
2203-007170	C2064	C-CERAMIC,CHIP
2203-007194	C1086	C-CERAMIC,CHIP
2203-007295	C2089	C-CERAMIC,CHIP
2203-007317	C5047,C5048,C5082	C-CERAMIC,CHIP
2203-007317	C5106,C7000,C7006	C-CERAMIC,CHIP
2203-007317	C7012,C7140,L5110	C-CERAMIC,CHIP
2203-007393	C5030,C5031,C5071	C-CERAMIC,CHIP
2203-007393	C5096	C-CERAMIC,CHIP
2203-007796	C7015,C7024,C7033	C-CERAMIC,CHIP
2203-008095	C5079	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008394	C2094,C3012	C-CERAMIC,CHIP
2203-008876	C1085,C1100,C5007	C-CERAMIC,CHIP
2203-008876	C5088,C5102	C-CERAMIC,CHIP
2203-009970	C7018,C7020,C7021	C-CERAMIC,CHIP
2203-009970	C7038,C7039,C7040	C-CERAMIC,CHIP
2703-002649	L1003,L1077,L2003	INDUCTOR-SMD
2703-002858	L2001,L2028	INDUCTOR-SMD
2703-002907	L1010,L1045,L1053	INDUCTOR-SMD
2703-002959	L2002,L2025,L2069	INDUCTOR-SMD
2703-002959	L3001	INDUCTOR-SMD
2703-004012	L1015,L1021,L1024	INDUCTOR-SMD
2703-004012	L1051,L1062,L1063	INDUCTOR-SMD
2703-004012	L1094	INDUCTOR-SMD
2703-004013	L1074,L2035	INDUCTOR-SMD
2703-004014	L1070	INDUCTOR-SMD
2703-004018	C2003,L2004,L3003	INDUCTOR-SMD
2703-004018	L3004	INDUCTOR-SMD
2703-004032	L1056,L1060,L2024	INDUCTOR-SMD
2703-004034	L1065,L1069,L2019	INDUCTOR-SMD
2703-004035	L1041,L1073,L2008	INDUCTOR-SMD
2703-004036	L1026	INDUCTOR-SMD
2703-004037	C3018,L1034,L1040	INDUCTOR-SMD
2703-004037	L1046,L1047,L1048	INDUCTOR-SMD
2703-004037	L1057,L2065	INDUCTOR-SMD
2703-004038	L1064,L1068,L1075	INDUCTOR-SMD
2703-004038	L2006	INDUCTOR-SMD
2703-004286	L1054,L1061,L2009	INDUCTOR-SMD
2703-004286	L2022	INDUCTOR-SMD
2703-004290	L1081	INDUCTOR-SMD
2703-004300	L1011,L1038,L1080	INDUCTOR-SMD
2703-004300	L2005	INDUCTOR-SMD
2703-004317	L1066,L1078,L1079	INDUCTOR-SMD
2703-004362	L1076,L2067	INDUCTOR-SMD
2703-004363	L2016	INDUCTOR-SMD
2703-004366	L1016,L1035,L1036	INDUCTOR-SMD
2703-004366	L2033,L2066,L3012	INDUCTOR-SMD
2703-004367	L1020,L1082,L2000	INDUCTOR-SMD
2703-004367	L5013	INDUCTOR-SMD
2703-004369	L1022,L1059,L2059	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004369	R3001	INDUCTOR-SMD
2703-004371	L1007,L1025,L1055	INDUCTOR-SMD
2703-004408	L1006,L1013,L1049	INDUCTOR-SMD
2703-004408	L3020	INDUCTOR-SMD
2703-004763	L1071,L2018	INDUCTOR-SMD
2703-004764	L2007	INDUCTOR-SMD
2703-004911	L1058	INDUCTOR-SMD
2901-001690	C4055	FILTER-EMI SMD
2904-002257	F2005	FILTER-SAW
2904-002280	F2000	FILTER-SAW
2904-002397	F1012	FILTER-SAW
2904-002428	F1007	FILTER-SAW
2910-000363	F1011	FILTER
3709-001936	SIM5000	CONNECTOR-CARD, EDGE
3712-001694	ANT3001,ANT5000	CONNECTOR
3712-001694	ANT5002,ANT6002	CONNECTOR

5. MAIN Electrical Parts List

[SM-A013G]

Parts Code	Design LOC	Description
0505-003618	Q5000	FET-SILICON
1001-002093	U1004	IC
1201-004219	U1002,U1003,U1007	IC
1201-004219	U2000,U2003	IC
2007-000143	R5035	R-CHIP
2007-003001	R6005,R6006	R-CHIP
2007-007766	R2000	R-CHIP
2007-008486	R5026	R-CHIP
2007-008516	R4013,R4014,R4026	R-CHIP
2007-008531	R5039	R-CHIP
2007-009171	R5030	R-CHIP
2007-009801	R5029	R-CHIP
2203-002677	C2037	C-CERAMIC,CHIP
2203-005682	C5094,C6012,C6015	C-CERAMIC,CHIP
2203-005682	C6016,C6017,C7037	C-CERAMIC,CHIP
2203-005682	C7041	C-CERAMIC,CHIP
2203-005736	C1022,C1024,C1030	C-CERAMIC,CHIP
2203-005736	C1031,C1032,C1038	C-CERAMIC,CHIP
2203-005736	C1050,C1053,C1064	C-CERAMIC,CHIP
2203-005736	C1065,C1071,C1076	C-CERAMIC,CHIP
2203-005736	C1078,C1080,C1089	C-CERAMIC,CHIP
2203-005736	C1092,C1099,C1111	C-CERAMIC,CHIP
2203-005736	C1125,C2000,C2002	C-CERAMIC,CHIP
2203-005736	C2005,C2009,C2010	C-CERAMIC,CHIP
2203-005736	C2011,C2012,C2013	C-CERAMIC,CHIP
2203-005736	C2014,C2015,C2016	C-CERAMIC,CHIP
2203-005736	C2017,C2018,C2021	C-CERAMIC,CHIP
2203-005736	C2023,C2027,C2028	C-CERAMIC,CHIP
2203-005736	C2029,C2030,C2032	C-CERAMIC,CHIP
2203-005736	C2033,C2034,C2036	C-CERAMIC,CHIP
2203-005736	C2038,C2039,C2040	C-CERAMIC,CHIP
2203-005736	C2042,C2047,C2048	C-CERAMIC,CHIP
2203-005736	C2049,C2050,C2052	C-CERAMIC,CHIP
2203-005736	C2056,C2057,C2059	C-CERAMIC,CHIP
2203-005736	C2068,C2069,C2097	C-CERAMIC,CHIP
2203-005736	C2099,C2105,C3002	C-CERAMIC,CHIP
2203-005736	C3006,C3010,C3011	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005736	C3013,C3014,C3028	C-CERAMIC,CHIP
2203-005736	C3029,C3030,C3031	C-CERAMIC,CHIP
2203-005736	C6008,C7022,C7025	C-CERAMIC,CHIP
2203-005736	L1043,L1050,L3009	C-CERAMIC,CHIP
2203-005777	C1039,C1040,C1041	C-CERAMIC,CHIP
2203-005777	C1084	C-CERAMIC,CHIP
2203-005789	C1000,C1013,C1017	C-CERAMIC,CHIP
2203-005789	C1019,C1033,C1037	C-CERAMIC,CHIP
2203-005789	C1051,C1061,C1063	C-CERAMIC,CHIP
2203-005789	C1074,C1090,C1091	C-CERAMIC,CHIP
2203-005789	C1095,C2092,L3019	C-CERAMIC,CHIP
2203-005806	C1067,C1072,C1073	C-CERAMIC,CHIP
2203-005806	C1152,C2004,C3016	C-CERAMIC,CHIP
2203-006123	C2041,L3000	C-CERAMIC,CHIP
2203-006305	C1077	C-CERAMIC,CHIP
2203-006318	C1088,C2091	C-CERAMIC,CHIP
2203-006410	C1048,C2093	C-CERAMIC,CHIP
2203-006423	C1049,C1104,C2001	C-CERAMIC,CHIP
2203-006423	C2026,C2046,C2066	C-CERAMIC,CHIP
2203-006423	C2067,C3026,C4002	C-CERAMIC,CHIP
2203-006423	C4017,C4020,C4021	C-CERAMIC,CHIP
2203-006423	C4027,C4029,C4031	C-CERAMIC,CHIP
2203-006423	C4033,C4035,C4037	C-CERAMIC,CHIP
2203-006423	C4038,C4040,C4044	C-CERAMIC,CHIP
2203-006423	C4060,C4061,C4065	C-CERAMIC,CHIP
2203-006423	C4067,C4068,C5037	C-CERAMIC,CHIP
2203-006423	C5045,C5046,C5053	C-CERAMIC,CHIP
2203-006423	C5054,C5073,C5081	C-CERAMIC,CHIP
2203-006423	C5091,C5092,C5120	C-CERAMIC,CHIP
2203-006423	C5121,C7144,C7146	C-CERAMIC,CHIP
2203-006604	C1027	C-CERAMIC,CHIP
2203-007170	C2064	C-CERAMIC,CHIP
2203-007194	C1086	C-CERAMIC,CHIP
2203-007295	C2089	C-CERAMIC,CHIP
2203-007317	C5047,C5048,C5082	C-CERAMIC,CHIP
2203-007317	C5106,C7000,C7006	C-CERAMIC,CHIP
2203-007317	C7012,C7140,L5110	C-CERAMIC,CHIP
2203-007393	C5030,C5031,C5071	C-CERAMIC,CHIP
2203-007393	C5096	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C7015,C7024,C7033	C-CERAMIC,CHIP
2203-008095	C5079	C-CERAMIC,CHIP
2203-008394	C2094,C3012	C-CERAMIC,CHIP
2203-008876	C1085,C1100,C5007	C-CERAMIC,CHIP
2203-008876	C5088,C5102	C-CERAMIC,CHIP
2203-009970	C7018,C7020,C7021	C-CERAMIC,CHIP
2203-009970	C7038,C7039,C7040	C-CERAMIC,CHIP
2703-002649	L1003,L1077,L2003	INDUCTOR-SMD
2703-002858	L2001,L2028	INDUCTOR-SMD
2703-002907	L1010,L1045,L1053	INDUCTOR-SMD
2703-002959	L1044,L2002,L2025	INDUCTOR-SMD
2703-002959	L2069,L3001	INDUCTOR-SMD
2703-004012	L1015,L1021,L1024	INDUCTOR-SMD
2703-004012	L1051,L1062,L1063	INDUCTOR-SMD
2703-004012	L1094	INDUCTOR-SMD
2703-004013	L1074,L2035	INDUCTOR-SMD
2703-004014	L1070	INDUCTOR-SMD
2703-004018	C2003,L2004,L3003	INDUCTOR-SMD
2703-004018	L3004	INDUCTOR-SMD
2703-004032	L1056,L1060,L2024	INDUCTOR-SMD
2703-004033	C1119	INDUCTOR-SMD
2703-004034	L1065,L1069,L2019	INDUCTOR-SMD
2703-004035	L1041,L1073,L2008	INDUCTOR-SMD
2703-004036	L1019,L1026,L2027	INDUCTOR-SMD
2703-004037	C3018,L1034,L1040	INDUCTOR-SMD
2703-004037	L1046,L1047,L1048	INDUCTOR-SMD
2703-004037	L1057,L2065	INDUCTOR-SMD
2703-004038	L1064,L1068,L1072	INDUCTOR-SMD
2703-004038	L1075,L2006	INDUCTOR-SMD
2703-004286	L1054,L1061,L2009	INDUCTOR-SMD
2703-004286	L2022	INDUCTOR-SMD
2703-004290	L1081	INDUCTOR-SMD
2703-004300	L1011,L1038,L1080	INDUCTOR-SMD
2703-004300	L2005	INDUCTOR-SMD
2703-004317	L1066,L1078,L1079	INDUCTOR-SMD
2703-004362	L1076,L2067	INDUCTOR-SMD
2703-004363	L2016	INDUCTOR-SMD
2703-004366	L1016,L1035,L1036	INDUCTOR-SMD
2703-004366	L2033,L2066,L3012	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004367	L1020,L1082,L2000	INDUCTOR-SMD
2703-004367	L5013	INDUCTOR-SMD
2703-004369	L1022,L1059,L2059	INDUCTOR-SMD
2703-004369	R3001	INDUCTOR-SMD
2703-004371	L1007,L1017,L1025	INDUCTOR-SMD
2703-004371	L1055	INDUCTOR-SMD
2703-004408	L1006,L1013,L1049	INDUCTOR-SMD
2703-004408	L3020	INDUCTOR-SMD
2703-004763	L1071,L2018	INDUCTOR-SMD
2703-004764	L2007	INDUCTOR-SMD
2703-004911	L1058	INDUCTOR-SMD
2901-001690	C4055	FILTER-EMI, SMD
2904-002257	F2005	FILTER-SAW
2904-002280	F2000	FILTER-SAW
2904-002397	F1012	FILTER-SAW
2904-002419	F2008	FILTER-SAW
2904-002428	F1007	FILTER-SAW
2910-000363	F1011	FILTER
2910-000417	F1010	FILTER
3709-001936	SIM5000	CONNECTOR-CARD, EDGE
3712-001694	ANT3001,ANT5000	CONNECTOR
3712-001694	ANT5002,ANT6002	CONNECTOR

5. MAIN Electrical Parts List

[SM-A013M]

Parts Code	Design LOC	Description
0202-002125	R5000,R5007,R5033	-
0202-002125	R5034,R6000,R6002	-
0202-002125	R6009	-
0202-002126	R6014,R6015,R6032	-
0505-003618	Q4000	FET-SILICON
1201-004219	U1002,U1007,U2000	IC
1201-004219	U2002,U2003	IC
2007-000143	R7017	R-CHIP
2007-007766	C2062	R-CHIP
2007-008486	R9004	R-CHIP
2007-008516	R4013,R4014,R4026	R-CHIP
2007-008531	R9003	R-CHIP
2007-009154	R6005,R6006	R-CHIP
2007-009171	R9005	R-CHIP
2007-009801	R9006	R-CHIP
2203-005682	C6012,C6015,C6016	C-CERAMIC,CHIP
2203-005682	C6017,C7037,C7041	C-CERAMIC,CHIP
2203-005736	C1022,C1024,C1029	C-CERAMIC,CHIP
2203-005736	C1030,C1032,C1038	C-CERAMIC,CHIP
2203-005736	C1050,C1053,C1065	C-CERAMIC,CHIP
2203-005736	C1071,C1078,C1080	C-CERAMIC,CHIP
2203-005736	C1089,C1092,C1111	C-CERAMIC,CHIP
2203-005736	C1125,C2000,C2003	C-CERAMIC,CHIP
2203-005736	C2005,C2006,C2008	C-CERAMIC,CHIP
2203-005736	C2010,C2011,C2013	C-CERAMIC,CHIP
2203-005736	C2014,C2015,C2016	C-CERAMIC,CHIP
2203-005736	C2017,C2018,C2023	C-CERAMIC,CHIP
2203-005736	C2027,C2028,C2030	C-CERAMIC,CHIP
2203-005736	C2033,C2034,C2036	C-CERAMIC,CHIP
2203-005736	C2038,C2039,C2040	C-CERAMIC,CHIP
2203-005736	C2042,C2047,C2048	C-CERAMIC,CHIP
2203-005736	C2050,C2051,C2052	C-CERAMIC,CHIP
2203-005736	C2056,C2057,C2059	C-CERAMIC,CHIP
2203-005736	C2068,C2069,C2097	C-CERAMIC,CHIP
2203-005736	C2099,C2102,C2103	C-CERAMIC,CHIP
2203-005736	C2105,C3002,C3006	C-CERAMIC,CHIP
2203-005736	C3010,C3011,C3013	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005736	C3014,C3028,C3029	C-CERAMIC,CHIP
2203-005736	C3030,C3031,C6008	C-CERAMIC,CHIP
2203-005736	C7022,C7025,L1047	C-CERAMIC,CHIP
2203-005736	L1050,L2030,L3009	C-CERAMIC,CHIP
2203-005777	C1039,C1040,C1079	C-CERAMIC,CHIP
2203-005789	C1000,C1017,C1019	C-CERAMIC,CHIP
2203-005789	C1033,C1034,C1035	C-CERAMIC,CHIP
2203-005789	C1051,C1057,C1063	C-CERAMIC,CHIP
2203-005789	C1090,C1091,C1095	C-CERAMIC,CHIP
2203-005789	L3019	C-CERAMIC,CHIP
2203-005806	C1064,C1152,C2004	C-CERAMIC,CHIP
2203-005806	C3016	C-CERAMIC,CHIP
2203-006123	L3000	C-CERAMIC,CHIP
2203-006305	C1041	C-CERAMIC,CHIP
2203-006318	C1048,C1073,C1088	C-CERAMIC,CHIP
2203-006423	C1049,C1104,C2012	C-CERAMIC,CHIP
2203-006423	C2026,C2029,C2046	C-CERAMIC,CHIP
2203-006423	C2066,C2067,C3026	C-CERAMIC,CHIP
2203-006423	C4002,C4017,C4020	C-CERAMIC,CHIP
2203-006423	C4021,C4027,C4029	C-CERAMIC,CHIP
2203-006423	C4031,C4033,C4035	C-CERAMIC,CHIP
2203-006423	C4037,C4038,C4040	C-CERAMIC,CHIP
2203-006423	C4044,C4060,C4061	C-CERAMIC,CHIP
2203-006423	C4065,C4067,C4068	C-CERAMIC,CHIP
2203-006423	C5037,C5045,C5046	C-CERAMIC,CHIP
2203-006423	C5053,C5054,C5073	C-CERAMIC,CHIP
2203-006423	C5081,C5091,C5092	C-CERAMIC,CHIP
2203-006423	C5120,C5121,C7144	C-CERAMIC,CHIP
2203-006423	C7146	C-CERAMIC,CHIP
2203-006604	C1074	C-CERAMIC,CHIP
2203-007317	C5047,C5048,C5071	C-CERAMIC,CHIP
2203-007317	C5082,C5106,C7000	C-CERAMIC,CHIP
2203-007317	C7006,C7012,C7140	C-CERAMIC,CHIP
2203-007317	L5110	C-CERAMIC,CHIP
2203-007393	C5030,C5031,C5096	C-CERAMIC,CHIP
2203-007795	C7020,C7021	C-CERAMIC,CHIP
2203-007796	C7010,C7015,C7024	C-CERAMIC,CHIP
2203-007796	C7033	C-CERAMIC,CHIP
2203-008095	C4091	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008394	C3012	C-CERAMIC,CHIP
2203-008876	C1085,C1100,C4092	C-CERAMIC,CHIP
2203-008876	C5007,C5102	C-CERAMIC,CHIP
2203-009970	C7018,C7038,C7039	C-CERAMIC,CHIP
2203-009970	C7040	C-CERAMIC,CHIP
2703-002649	L1003,L1035,L1077	INDUCTOR-SMD
2703-002649	L2003	INDUCTOR-SMD
2703-002901	L1009	INDUCTOR-SMD
2703-002907	L1053	INDUCTOR-SMD
2703-002951	L1019,L2011	INDUCTOR-SMD
2703-002953	L2016	INDUCTOR-SMD
2703-002959	L1044,L2002,L2006	INDUCTOR-SMD
2703-002959	L2069,L3001	INDUCTOR-SMD
2703-004012	L1015,L1018,L1062	INDUCTOR-SMD
2703-004012	L1063,L1094	INDUCTOR-SMD
2703-004013	L1021,L2008,L2035	INDUCTOR-SMD
2703-004014	L1071	INDUCTOR-SMD
2703-004018	L2009,L3003,L3004	INDUCTOR-SMD
2703-004032	L1006,L1060	INDUCTOR-SMD
2703-004033	L1010	INDUCTOR-SMD
2703-004034	C1013,L1041,L1056	INDUCTOR-SMD
2703-004034	L2019	INDUCTOR-SMD
2703-004035	L1045,L2013	INDUCTOR-SMD
2703-004036	L1026,L1069	INDUCTOR-SMD
2703-004037	C3018,L1007,L1011	INDUCTOR-SMD
2703-004037	L1025,L1034,L1040	INDUCTOR-SMD
2703-004037	L1048,L1072,L1075	INDUCTOR-SMD
2703-004037	L2017	INDUCTOR-SMD
2703-004038	C2049,L1024,L1057	INDUCTOR-SMD
2703-004038	L1070	INDUCTOR-SMD
2703-004286	L1054,L1061,L1073	INDUCTOR-SMD
2703-004286	L2007,L2022	INDUCTOR-SMD
2703-004300	L1038,L1051,L1068	INDUCTOR-SMD
2703-004317	L1064,L1066	INDUCTOR-SMD
2703-004328	L1043,L1046,L2000	INDUCTOR-SMD
2703-004328	L2004,L2012	INDUCTOR-SMD
2703-004362	L1076	INDUCTOR-SMD
2703-004366	L1016,L1036,L2021	INDUCTOR-SMD
2703-004366	L2033,L3012	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004367	C1109,L1020,L5013	INDUCTOR-SMD
2703-004369	L1022,L1059,R3001	INDUCTOR-SMD
2703-004371	L1017,L1055	INDUCTOR-SMD
2703-004408	L1013,L3020	INDUCTOR-SMD
2703-004763	L1058	INDUCTOR-SMD
2901-001690	C4055	FILTER-EMI, SMD
2904-002339	F2006	FILTER-SAW
2904-002419	F2008	FILTER-SAW
2910-000296	F1012	FILTER
2910-000416	F1007	FILTER
2910-000417	F1010	FILTER
3709-001936	SIM5000	CONNECTOR-CARD
3712-001604	ANT5000,ANT5002	CONNECTOR
3712-001694	ANT3001,ANT6002	CONNECTOR

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.